



BCR230 PRODUCT USER TRAINING

GET STARTED

1. Ensure device is fully charged;
2. Application is installed;
3. Connect device (Bluetooth / USB) to Mobile and or Desktop;

HOW TO USE

Jog Dial

Use this to navigate device
Firmly press downwards

A) Power On
Hold 5sec  screen turn with a "beep"

B) Power Off
Push down till "Device OPR turn off device?" to Power Off device, Device will blink once before turning off

C) Check Bluetooth Status
Push down to "BLUETOOTH INFO" to see status, Ensure device is on "Visible" in order to connect. Device will not be able to pair if status is on "Invisible"


D) Setup Bluetooth 4.0
Turn on mobile application and pair device directly via mobile application

E) Setup Bluetooth 2.0
Push down to "BLUETOOTH OPR", press to select or change Bluetooth status. To pair device, press and select "Set Visible"

Once device is set visible, Push jog upwards to see Passkey (Bluetooth Pin) information and insert into mobile phone to pair.

F) Read MyKad
Push down to "MYKAD MODE", press once to start verification. To verify, insert MyKad.

Place fingerprint onto the fingerprint scanner to verify fingerprint when the scanner is blinked in red, Device will "Beep" once verification is done.



CONNECTIVITY



Check Device Bluetooth Status

Ensure device status is set as "Visible"

To enable device for bluetooth connectivity

- If status does not appear as "Visible";
- Look for the jog dial (on the left side on the device) on the device;
- Firmly press downward on the jog dial, select "Bluetooth Operation";
- Firmly press downward on the jog dial to select and change the selection;
- Ensure to press until the function is selected;

LCD MESSAGE ON DEVICE



Device Initialized




Device is connect
and ready to use



Time & Date setup




Device BT2.0 Passkey



Device Connectivity
Status



MyKad verification
function




MyKad verified
information



Device at charging
mode

OPERATE THE DEVICE




PRODUCT PERFORMANCE
PRODUCT VIDEO

INNOVATE
SECURED AND TRUSTED
AUTHENTICATION




DOWNLOAD APPLICATION PATH TO DOWNLOAD



1. Enter <http://www.pradotec-global.com> website
2. Go to “Download” – download Product Driver & Desktop Application

DOWNLOAD APPLICATION REQUEST ACCESS



Google

Sign in
to continue to Google Drive

Email or phone

[Forgot email?](#)

Not your computer? Use Guest mode to sign in privately.
[Learn more](#)

[Create account](#) [Next](#)

Google Drive


You need access

Ask for access, or switch to an account with access.
[Learn more](#)

Message (optional)

[Request access](#)

You are signed in as

 chelleleetang@gmail.com



1. Log in with email to send in request.
2. Insert information of purchase in message box, please provide: Company name & invoice number # as reference

INSTALLATION OF APPLICATION

STEPS OF INSTALLATION

1. Install Product Driver
2. Install Desktop Application
3. Plug in BCR230 device
4. Start using